



Video Doorbell

Features




- 1. Motion Sensor
- 2. Wide-angle Lens
- 3. Light Sensor
- 4. Hidden Infrared Lights
- 5. Microphone
- 6. Doorbell Button
- 7. Indicator Lights
- 8. Speaker



- 9. Restart Button
- 10. Micro USB Port (Battery Charging)

Indicator Light



Indicator light flashing RED

The device is reconnecting to the Wifi network. Please wait.



Indicator light flashing RED and BLUE alternately



Low battery. Please recharge your batteries.

In the box



Video Doorbell



Mounting Bracket



Tape



5 Anchors



5 Mounting Screws



2 Security Screws



User Manual



2 Batteries (Optional)




Chime (Optional)

Charge batteries

1. Remove the battery tab.




2. Insert 18650 batteries positive end facing down, as shown on the device.



Rechargeable 18650 Battery

3. Fully charge batteries by connecting your device to a USB charger using a Micro USB cable. It takes about 14 hours for batteries to fully charge.



WARNING: Lots of events

If your device is capturing an excessive number of events every day, you might need to recharge your battery sooner. Plus, the battery is also drained each time you use the Live View to look or speak through your doorbell. To prevent excessive events, you can adjust your motion settings to a lower sensitivity.

Set up your Video Doorbell

Step 1

Scan the QR codes below or search for Aiwit on the Apple app store or Google Play to download the app. The app will walk you through setting up your doorbell.




Aiwit



Android / iOS
App Download


Step 2

Open the Aiwit app on your cellphone. Tap Log in/Sign up. Then tap sign up.




Step 3

Enter your email and password, then tap Sign up.




Step 4

You will receive an email with the confirmation code. Please enter the code and tap Confirm.




Step 5

Enter your email and password, then tap Log in.




Step 6

Tap + .



Step 7

Select Video doorbell.



Step 8

Press and hold the doorbell button for 8 seconds until the doorbell light is flashing red. Tap Next.




Step 9

Tap Yes.




Step 10

Find or enter the name of your Wifi network and enter the Wifi password. Tap Next.



Step 11


Scan the QR code using the doorbell camera. Keep devices 4 inches (10 cm) apart.



This device only supports 2.4GHz Wi-Fi.


Step 12

If pairing is successful, you will see a message as below.



Step 13


After setup, tap the Live View in the Aiwit app to see live video from your doorbell.




Install your Video Doorbell

Mark drill holes and use a bit to drill holes in your wall. Insert anchors and secure your doorbell with mounting and security screws.


Step 1




Step 2



Step 3



Step 4



Frequently asked questions

How long do my videos stay in my account?

Your videos are stored in the Free Cloud for up to 7 days.

How to RESET the doorbell

Press and hold the Doorbell Button for 8 seconds. Then follow the in-app instructions to finish your Wi-Fi setup.

How to share the device with my family

Open the Aiwit app. From the home page, tap the Share icon. Tap Share via Email or Share via QR Code. You can share the device with up to 8 users.

Share via Email:

The new user has to download the Aiwit app and create an account with the same email address which the device owner has shared with. Log in to the account and you'll see the shared device.

Share via QR Code:

1. Open the Aiwit App on a new user's smartphone.
2. From the home page, tap +.
3. Tap **QR Code Sharing**, then scan the QR code the device owner generated before.
4. You will see **Share successful**, then tap **Confirm**.

How many users can view the video at the same time?

Up to 3 users may view the video feed, but only 1 user can use the direct intercom. Both iOS and Android are compatible

Is 5GHz Wi-Fi supported?

No. Only 2.4GHz Wi-Fi is supported.

Why is my Wi-Fi signal poor on my device?

Your device may be too far away from your wireless router or you may have some obstructions in between that reduce signal strength. You might try repositioning your router or getting a signal extender/repeater for your wireless router.

How to adjust Motion Detection Sensitivity

From the home page, tap the Motion Detection icon.

Motion Detection Sensitivity

- **Fast:** Records and notifies you about every motion. Shortest battery life.
- **Medium:** Records and notifies you about motion less often. Standard battery life.
- **Slow:** Records and notifies you about motion even less often. Maximum battery life.

How to enable Notifications on my phone

To do this, you need to give permission for the Aiwit app to access to your microphone and enable notifications.

Follow these steps to enable notifications.

1. Open Settings. Go to Aiwit app permissions and select Notifications.
2. Make sure all switches are on.


Set up your Wireless Chime (Optional)

Connect the video doorbell to the doorbell chime, and get instant alert in your home when someone rings the doorbell. The chime plugs into any wall outlet, you can place it anywhere in the home.

NOTICE:

The video doorbell is only compatible with our wireless chime, and not compatible with traditional doorbell chimes. The wireless chime is optional. If it is not installed, doorbell notifications will still go directly to the Aiwit app.



The Basics



Set up your chime with the video doorbell.


Step 1

Before the setup process, be sure your video doorbell has connected to your phone and plug in your chime.




Step 2

Press the Connect Button.




Step 3

Press the Doorbell Button to pair your doorbell to the chime.



Step 4

Press the Tune Button to cycle through 38 different tunes and select a tune.



Step 5

Press the Doorbell Button again to make sure it's the tune you selected.

